

Tool Model	Part NO	Part Code	Description
HN75	1	HN10067	SCREW 6 X35
HN75	2	HN11511	CYLINDER CAP
HN75	3	HN10773	CYLINDER CAP SEAL
HN75	4	KK23650	COMP SPRING 3650
HN75	5	HN10774	PISTON STOP
HN75	6	HH19719	O-RING 1A2.6X54.5
HN75	7	HH11157	O-RING ARP568-136 850006
HN75	8	HN10776	HEAD VALVE PISTON
HN75	9	HN11443	HEAD VALVE GUIDE
HN75	10	HH14729	O-RING AS568-144
HN75	11	HH11806	O-RING P27
HN75	12	HN70133	MAIN PISTON UNIT
HN75	13	HN10780	CYLINDER SEAL
HN75	14	HH19200	O-RING 1A 2.6 X 52.5 <<<<<<
HN75	15	HH11109	O-RING 1AP40 <<<<<<
HN75	16	HN81132	CYLINDER ASSY
HN75	17	HH19196	O-RING 1A 4.9X43 851439
HN75	18	HN10779	CYLINDER B
HN75	19	HN10807	BUMPER
HN75	20	HN81061	EXHAUST COVER UNIT
HN75	21	HS10078	FILTER B
HN75	22	HS10077	FILTER A
HN75	23	HN81062	FRAME
HN75	24	CN34309	PLASTIC SHEET LABEL (100421)
HN75	25	HN10810	NAME LABEL A
HN75	26	HN10811	NAME LABEL B
HN75	27	KK23507	SPRING 3507
HN75	28	HN12123	TRIGGER LOCK DIAL
HN75	29	FF21235	SPRING PIN 3X30
HN75	30	HH11120	O-RING ARP568-009 CN65079
HN75	31	HN11442	PIPE
HN75	32	HH19127	O-RING A 1.5X5.5
HN75	33	HN10379	GRIP COVER
HN75	34	CN35075	TRIGGER LOCK LEVER
HN75	35	HS10704	SCREW 6X38
HN75	36	TA17024	FILTER A
HN75	37	HH19102	O-RING 1A 2.4X31.8 T29011(REPLACES TA15265)
HN75	38	HN12037	END CAP
HN75	39	HN10316	END PLUG CAP
HN75	40	TT05416	AIR PLUG
HN75	41	HN10017	PILOT VALVE
HN75	42	BB40470	SCREW 5X32
HN75	44	HN10820	FEED NOZZLE
HN75	45	HH19722	O-RING A1.5X5
HN75	46	HN10043	PILOT CAP
HN75	47	HN10018	PILOT SEAL
HN75	48	HH12105	O-RING 1A 1.5 X 12.8 N5521
HN75	49	HN10016	TRIGGER VALVE HOUSING
HN75	51	HH11208	O-RING P6 (HH11804 replaced)
HN75	52	HS10139	PILOT VALVE
HN75	53	HH11132	O-RING 1AP10A CN65072

Tool Model	Part NO	Part Code	Description
HN75	54	KK23906	COMP. SPRING 3906
HN75	56	HH19707	O-RING A1.4X2.5
HN75	57	HS10141	TRIGGER VALVE STEM
HN75	58	HH19214	O-RING 1B 1.5X3
HN75	59	HS10140	TRIGGER VALVE CAP
HN75	60	HS80014	TRIGGER ASSY
HN75	61	KN12635	CONTACT LEVER B
HN75	62	HS10143	CONTACT LEVER A
HN75	63	KN12401	TRIGGER
HN75	64	FF22402	SPRING PIN 3X16 (LIGHT LOAD)
HN75	65	HS10145	SWITCH LEVER A
HN75	66	HN10786	ARM GUIDE PLATE
HN75	67	HS10146	SWITCH LEVER B
HN75	68	CN34500	SPRING, LEVER
HN75	69	KK23735	COMPRESSION SPRING 3735
HN75	70	KK23736	COMPRESSION SPRING 3736
HN75	71	KK23129	COMPRESSION SPRING 3129
HN75	72	HN10784	ARM GUIDE
HN75	73	HN10785	CONTACT BUMPER
HN75	74	HN10818	CONTACT ARM A
HN75	75	HN10026	ADJUST DIAL
HN75	76	HN11981	ADJUST SPACER
HN75	77	HH14734	O-RING AS568-031
HN75	78	HN11447	NOSE
HN75	79	EE39602	WASHER 7
HN75	80	BB40224	SCREW 7X25
HN75	81	CN33679	DOOR LUTCH
HN75	82	KK33353	SPRING 3353
HN75	83	FF41599	PIN 1599 (REPLACES FF41587)
HN75	84	HN11449	DOOR
HN75	85	FF41817	STEP PIN 1817
HN75	86	HN10797	RATCHET
HN75	87	KK23912	COMP. SPRING 3912
HN75	88	EE39609	RUBBER WASHER 1.8X6X2
HN75	89	FF31520	STRAIGHT PIN 1520
HN75	90	BB40460	BOLT 5 X 28
HN75	91	HN10790	CONTACT BOLT
HN75	92	HH11903	O-RING 1A 1.2 X 4 T29051(REPLACES TA15277)
HN75	93	KK23952	COMP. SPRING 3901 (KK23901 replaced)
HN75	94	HN70134	CONTACT ARM B UNIT
HN75	95	JJ10404	E-RING 3.2
HN75	96	HN10817	CONTACT TIP
HN75	97	FF31294	PIN 1294
HN75	98	CN35336	CHECK PAWL
HN75	99	KK33337	SPRING 3337
HN75	100	HN11448	FEED PAWL
HN75	101	KK23710	COMP. SPRING 3710
HN75	102	KK23788	COMP. SPRING 3788
HN75	103	FF42216	STEP PIN 2216
HN75	104	HN11452	ARM COVER
HN75	105	CC00401	ELASTIC STOP NUT M5

<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
HN75	106	HH11111	O-RING 1AP 14 N5522(REPLACES TA15260)
HN75	107	HN10463	FEED PISTON
HN75	108	HH11107	O-RING AP18
HN75	109	KK23926	COMP. SPRING 3926
HN75	110	KK23927	COMP. SPRING 3927
HN75	111	CN37528	FEED PISTON STOP
HN75	112	HN10464	COMP. SPRING
HN75	113	JJ22407	C-RING 26
HN75	114	CN37383	SPRING HOOK (CN30602 replaced)
HN75	115	KK13144	SPRING 3144 (SUPERCEDES KK13040)
HN75	116	CN30601	SPACER CN65091
HN75	117	FF41287	PIN 1287
HN75	118	HN11450	MAGAZINE
HN75	119	HN10857	PROTECTOR M
HN75	120	HN10123	NAIL SUPPORT
HN75	121	CN37428	POST CAP
HN75	122	HN10856	FRAME HANGER
HN75	123	HN10357	CONTACT BUMPER
HN75	124	HN10853	MAGAZINE CAP
HN75	125	HN10400	ARM GUIDE PIN
HN75	126	HS10118	TRIGGER
HN75	127	HN11512	WARNING LABEL
HN75	130	HN11453	DUST COVER
HN75	131	BB40427	T-BOLT 4 X 8(REPLACES TA15544)
HN75	132	EE39172	WASHER 5.1X12X1.2
HN75	133	CN31083	HOOK, DUST COVER
HN75	145	HN10783	PROTECTOR
HN75	146	HN10819	EXHAUST COVER
HN75	147	HN81068	ARM GUIDE KIT
HN75	148	HN81069	SEQUENTIAL TRIP KIT
HN75	149	HN81070	O-RING KIT
HN75	150	HS80007	TRIGGER VALVE KIT
HN75	152	HN81083	FRAME HANGER KIT
HN75	153	HN81084	PROTECTOR M KIT
HN75	160	KK23619	COMP. SPRING 3619
HN75	161	HN10353	TRIGGER VALVE STEM
HN75	162	HN10019	TRIGGER VALVE CAP
HN75	163	HN10100	CONTACT LVER
HN75	164	KK33300	SPRING 3300
HN75	165	HS10117	CONTACT ARM A GUIDE
HN75	166	HN10401	CONTACT ARM A