

Tool Model	Part NO	Part Code	Description
HS90A	1	HN10067	SCREW 6 X35
HS90A	2	HS70021	CYLINDER CAP UNIT
HS90A	3	HS10074	CYLINDER CAP SEAL
HS90A	4	KK23650	COMP SPRING 3650
HS90A	5	HH11120	O-RING ARP569-009
HS90A	6	HS10073	PIPE
HS90A	7	HS10072	PISTON STOP
HS90A	8	HH11141	O RING ARP568-138
HS90A	9	HH11162	O-RING ARP568-140
HS90A	10	HS10070	HEAD VALVE PISTON
HS90A	11	HH14162	O-RING AS 568-141
HS90A	12	HS10071	HEAD VALVE GUIDE
HS90A	13	HH19715	O-RING A2.6X59.4
HS90A	14	HH11813	O-RING P32
HS90A	15	HS70030	MAIN PISTON UNIT
HS90A	16	HS10080	CYLINDER SEAL
HS90A	17	HH19724	O-RING A3.1X44
HS90A	18	HS10079	CCYLINDER
HS90A	19	HH19192	O-RING 1A3,1X56,5
HS90A	20	HS10081	BUMPER
HS90A	21	HH11908	O-RING A1.5X47
HS90A	22	HS10077	FILTER A
HS90A	23	HS10078	FILTER B
HS90A	24	HN81053	EXHAUST COVER ASSY
HS90A	25	HN10819	EXHAUST COVER
HS90A	26	HN10783	PROTECTOR
HS90A	27	HN11594	NAME LABEL A
HS90A	28	HN12123	TRIGGER LOCK DIAL
HS90A	29	KK23507	COMPRESSION SPRING 3507
HS90A	30	FF21235	SPRING PIN 3 X 30
HS90A	31	HN11595	NAME LABEL B
HS90A	32	CN35075	TRIGGER LOCK LEVER
HS90A	33	HN10379	GRIP COVER
HS90A	34	CC49411	SPECIAL NUT M5
HS90A	41	HH19102	O-RING 1A2,4X31,8
HS90A	43	HN12037	END CAP, REPLACES HN10517
HS90A	44	HN10316	END PLUG CAP
HS90A	45	HN70264	AIR PLUG H-FPM, REPLACES TT05425
HS90A	46	HH19722	O-RING A1.5X5
HS90A	47	HH19127	O-RING 1A1.5X5.5
HS90A	48	HN10043	PILOT CAP
HS90A	49	HN10018	PILOT SEAL
HS90A	50	HH12105	O-RING 1A1.5X12.8
HS90A	51	HN10016	TRIGGER VALVE HOUSING
HS90A	52	HH11208	O-RING BP6, REPLACES HH11804
HS90A	53	HS10772	PILOT VALVE
HS90A	54	HH11132	O-RING 1AP10A
HS90A	55	KK24165	COMP. SPRING 4165
HS90A	56	HH19707	O-RING 1A1,4X2,5
HS90A	57	HS10774	TRIGGER VALVE STEM
HS90A	58	HH19214	O-RING 1B 1.5X3

<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
HS90A	59	HS10773	TRIGGER VALVE CAP
HS90A	60	KN12635	CONTACT LEVER B REPLACES HS10144
HS90A	61	KN12401	TRIGGER, REPLACES HS10147
HS90A	62	HS10143	CONTACT LEVER A
HS90A	63	FF22402	SPRING PIN 2X16
HS90A	64	HN10358	ARM GUIDE PIN
HS90A	65	HS10145	SWITCH LEVER A
HS90A	66	KK23129	COMPRESSION SPRING 3129
HS90A	67	HS10146	SWITCH LEVER B
HS90A	68	CN34500	SPRING LEVER
HS90A	69	HS10148	ARM GUIDE
HS90A	70	KK23653	COMP SPRING 3653
HS90A	71	HN10818	CONTACT ARM A
HS90A	72	HN10357	CONTACT BUMPER
HS90A	73	HS70025	NOSE A UNIT
HS90A	74	KK23864	COMP SPRING 3864
HS90A	75	CC00401	ELASTIC STOP NUT M5
HS90A	76	HS70024	CONTACT ARM B UNIT
HS90A	77	KK23643	COMPRESSION SPRING 3643
HS90A	78	LL71806	STEEL BALL 3
HS90A	79	HS10088	ADJUST DIAL
HS90A	80	HS10087	CONTACT BOLT
HS90A	81	BB40221	SCREW M8X25
HS90A	82	CN32712	ADJUST STOPPER
HS90A	83	HS10086	CONTACT ARM C
HS90A	84	BB40401	BOLT 5X22
HS90A	85	HS10123	DOOR LATCH
HS90A	86	KK23868	COMP SPRING 3868
HS90A	89	HS10121	DOOR
HS90A	90	BB40406	SCREW M5x12
HS90A	91	EE31121	WASHER 1-5
HS90A	92	FF51520	PIN 1520
HS90A	94	HS10093	FEED PAWL A
HS90A	95	EE39602	RUBBER WASHER 7, REPLACES EE39604, EE39623
HS90A	96	KK23861	COMP SPRING 3861
HS90A	97	FF41844	PIN 1844
HS90A	98	HS10094	FEED PAWL B
HS90A	99	KK23710	COMP. SPRING 3710
HS90A	100	HS10098	LEVER
HS90A	101	EE39609	RUBBER WASHER 1.8X6.2
HS90A	102	KK23717	COMP SPRING 3717
HS90A	104	KK33326	SPRING 3326
HS90A	105	HS10097	CHECK PAWL C
HS90A	106	FF31264	STRAIGHT PIN 1264
HS90A	107	HS10096	CHECK PAWL B
HS90A	108	HS10130	GUIDE
HS90A	110	FF31291	PIN 1291
HS90A	111	KK23900	COMP. SPRING 3900
HS90A	112	KK23843	COMP SPRING 3843
HS90A	113	KK23863	COMP SPRING 3863
HS90A	114	EE39121	PLAIN WASHER 5

<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
HS90A	115	HS10129	NAIL HOLDER
HS90A	116	HS10128	CHECK PAWL D
HS90A	117	FF31290	PIN 1290
HS90A	118	KK23867	COMP SPRING 3867
HS90A	119	HS70026	SLIDE PLATE UNIT
HS90A	120	HS10124	SLIDE PLATE GUIDE A
HS90A	121	HS10125	SLIDE PLATE GUIDE B
HS90A	122	HS10122	DOOR COVER
HS90A	123	FF31288	PIN 1288
HS90A	124	HS10100	NAIL GUIDE
HS90A	126	HS10099	MAGAZINE
HS90A	132	BB40405	BOLT 5X25
HS90A	133	HS10131	ARM COVER
HS90A	135	HS10091	FEED PISTON
HS90A	136	HH11143	O-RING 1AP21
HS90A	137	KK23845	COMP SPRING 3845
HS90A	139	HS10092	SPRING GUIDE
HS90A	140	JJ10509	E-RING 4CF, REPLACES JJ10101
HS90A	141	HS10090	NOSE B
HS90A	142	HS10151	FEED NOZZLE
HS90A	143	HS10150	FILTER C
HS90A	144	HH19127	O-RING 1A1.5X5.5
HS90A	145	CN37528	FEED PISTON STOP, REPLACES CN31570
HS90A	146	HS10095	CHECK PAWL A
HS90A	147	HH11111	O-RING 1AP14
HS90A	148	KK23862	COMP SPRING 3862
HS90A	149	HH19714	O-RING 1A1,5X20,5
HS90A	150	HN10019	TRIGGER VALVE CAP
HS90A	151	TA17024	FILTER A, REPLACES CN33690, HN10752
HS90A	152	HS10108	NAME LABEL (HS90 USA)
HS90A	153	HS10763	WARNING LABEL
HS90A	154	HN10100	CONTACT LEVER
HS90A	155	HS10118	TRIGGER
HS90A	156	HN10400	ARM GUIDE PIN
HS90A	157	HS10117	CONTACT ARM A GUIDE
HS90A	159	HN10401	CONTACT ARM A
HS90A	160	KK23736	COMPRESSION SPRING 3736
HS90A	161	KK23735	COMPRESSION SPRING 3735
HS90A	162	KK33300	SPRING 3300
HS90A	163	HN10017	PILOT VALVE
HS90A	164	HN10353	TRIGGER VALVE STEM
HS90A	165	HS80026	FRAME ASSY
HS90A	166	HS10779	SWITCHING LEVER
HS90A	167	KK24166	COMP. SPRING 4166
HS90A	168	HS10764	SWITCHING LABEL
HS90A	169	HN11777	BELT HOOK, REPLACES HS10132
HS90A	170	HS10133	HOOK PIN
HS90A	171	JJ10509	E-RING 4CF, REPLACES JJ10101
HS90A	172	EE39172	PLAIN WASHER 5.1X12X1.2
HS90A	173	KK23844	COMP. SPRING 3844
HS90A	201	HS80011	O-RING KIT FOR HS90

<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
HS90A	202	HS80025	TRIGGER VALVE KIT
HS90A	203	HS80006	ARM GUIDE KIT
HS90A	204	HS80010	SEQUENTIAL TRIGGER KIT