


# TA238B/18-6

**EXPLODED  
VIEW AND SPARE PARTS LIST**

**SCHEMA ECLATE ET LISTE DES  
PIECES DE RECHANGE**

**DESPIECE DE LA MAQUINA Y LISTA  
DE RECAMBIOS**



<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
TA238B/18-6	1	TA19210	HEX. SOC. HD. CAP SCREW ASSY
TA238B/18-6	2	TA19136	CYLINDER CAP
TA238B/18-6	3	TA19137	EXHAUST SEAL
TA238B/18-6	4	TA19138	COMPRESSION SPRING
TA238B/18-6	5	TA19139	HEAD VALVE GUIDE
TA238B/18-6	6	TA19140	O-RING 9140
TA238B/18-6	7	TA19142	HEAD VALVE PISTON
TA238B/18-6	8	TA19143	O-RING 9143
TA238B/18-6	9	TA19144	O-RING 9144
TA238B/18-6	10	TA19145	CYLINDER CAP SEAL
TA238B/18-6	11	TA19915	DRIVER UNIT
TA238B/18-6	12	TA19208	CYLINDER WASHER
TA238B/18-6	13	TA19146	CYLINDER
TA238B/18-6	14	TA19148	CHECK PAWL
TA238B/18-6	15	TA19149	CYLINDER RING
TA238B/18-6	16	TA19907	BUMPER
TA238B/18-6	17	TA70351	FRAME UNIT
TA238B/18-6	18	TA18930	NAME PLATE
TA238B/18-6	19	TA19180	SPRING PIN
TA238B/18-6	20	TA19328	NOZZLE
TA238B/18-6	21	TA19170	HEX. SOC. HD. CAP SCREW
TA238B/18-6	22	TA19171	HOOK
TA238B/18-6	23	TA19172	ELASTIC STOP NUT
TA238B/18-6	24	TA19168	END CAP SEAL
TA238B/18-6	25	TA19169	END CAP
TA238B/18-6	26	TA19141	O-RING 9141
TA238B/18-6	27	TA19329	HEX.SOC.HD.CAP.SCREW
TA238B/18-6	28	TA19347	COLLAR B
TA238B/18-6	29	TA19156	TRIGGER VALVE HEAD
TA238B/18-6	30	TA19157	SPRING
TA238B/18-6	31	TA19158	TRIGGER VALVE STEM
TA238B/18-6	32	TA19162	TRIGGER VALVE GUIDE
TA238B/18-6	33	TA19163	SPRING
TA238B/18-6	34	TA19164	TRIGGER UNIT
TA238B/18-6	35	TA19198	ARM GUIDE
TA238B/18-6	36	TA19199	SPRING
TA238B/18-6	37	TA19200	CONTACT ARM A
TA238B/18-6	38	TA19201	C-RING
TA238B/18-6	39	TA19182	ADJUST DIAL
TA238B/18-6	40	TA19343	CONTACT ARM B
TA238B/18-6	41	TA19266	CONTACT TOP
TA238B/18-6	42	TA19052	HEX.SOC.HD.CAP SCR.ASSY
TA238B/18-6	43	TA19254	COLLAR
TA238B/18-6	44	TA19330	FRONT COVER
TA238B/18-6	45	TA19331	DRIVER GUIDE
TA238B/18-6	46	TA19332	WARE PLATE
TA238B/18-6	47	TA81353	MAGAZINE ASSY (AFTER)
TA238B/18-6	48	TA19340	PUSHER STOPPER
TA238B/18-6	49	TA19346	TAPPING SCREW
TA238B/18-6	50	TA19341	E-RING
TA238B/18-6	51	TA19215	O-RING 9215

<b>Tool Model</b>	<b>Part NO</b>	<b>Part Code</b>	<b>Description</b>
TA238B/18-6	52	TA19342	HEX.SOC.HD.CAP.SCREW
TA238B/18-6	53	TA19338	STEP PIN
TA238B/18-6	54	TA19339	SPRING
TA238B/18-6	55	TA19337	CLICK LEVER
TA238B/18-6	56	TA19352	SPRING PIN
TA238B/18-6	57	TA19333	PUSHER
TA238B/18-6	58	TA19334	PUSHER GUIDE
TA238B/18-6	59	TA19335	SPRING
TA238B/18-6	60	TA19344	SLIDER
TA238B/18-6	61	TA19336	TAIL COVER
TA238B/18-6	62	TA19306	WARNING LABEL
TA238B/18-6	63	TA19925	NAME LABEL(CE&USA)
TA238B/18-6	64	TA19209	O-RING 9209
TA238B/18-6	65	TA19147	O-RING 9147
TA238B/18-6	66	TA19150	O-RING 9150
TA238B/18-6	67	TA19155	O-RING 9155
TA238B/18-6	68	TA19159	O-RING 9159
TA238B/18-6	69	TA19160	O-RING 9160
TA238B/18-6	70	TA19161	O-RING 9161
TA238B/18-6	71	TA19165	SPRING PIN
TA238B/18-6	72	TA19173	EXHAUST FILTER
TA238B/18-6	101	TA81265	O-RING KIT
TA238B/18-6	102	TA81266	TRIGGER VALVE ASSY